

راهنمای فارسی

Ergo 8100S

ماوس بی سیم و بی صدا



تهیه شده در بخش خدمات پس از فروش شرکت شاب

آدرس: تهران، چیدرز، میدان ندا، پلاک ۵۸

تلفن: (۱۰ خط) ۲۲۶۸۶۱۸

www.shobtech.com

technical@shobtech.com



معرفی محصول :

ماوس بی سیم و بی صدا با طراحی ارگونومیک با تکیه گاه شست و انگشت برای جلوگیری از خستگی مچ دست و انگشتان به همراه ۶ دکمه با قابلیت کلیک بی صدا که دارای فناوری اتصال پایدار نیز هست. فقط کافی است دستگاه را وصل کنید تا از آزادی wireless و بدون سیم لذت ببرید.



امکانات دستگاه :

- بی سیم با فناوری اتصال پایدار بی سیم ۲,۴ گیگاهرتز با فاصله کاری تا ۱۰ متر
- ارگونومیگ با تکیه گاه شست و جای انگشت
- کلیک آرام و بی صدا برای آسایش بیشتر
- کلید تغییر DPI برای تغییر سرعت و دقت نشانگر ماوس از ۸۰۰ تا ۱۶۰۰
- بدون نیاز به برنامه نصب و درایور ماوس بی سیم ارگونومیگ

محتویات داخل جعبه :

- یک عدد ماوس Ergo 8100S
- یک عدد گیرنده / فرستنده USB متصل به ماوس
- یک عدد باتری قلمی AA
- راهنمای چند زبانه

سیستم مورد نیاز :

- Windows 8, 10, 11
- Mac OS X 10.8 یا به بعد
- پورت USB آزاد

مشخصات دستگاه Ergo 8100S :

Model name: Ergo 8100S

RF frequency: 2.4GHz wireless

Sensor engine: Optical

Number of buttons: 6 (Left, Right, Middle button with scroll, DPI Switch, Forward, Backward)

Resolution (DPI): 800 / 1200 (default) / 1600

Silent: Yes

Product dimensions: 67.8 x 109.5 x 38.4

(W x H x D) mm (inches): (2.67" x 4.31" x 1.51")

Product weight: Approx. 60 g

Colors: Black, Iron grey, Champagne titanium