

راهنمای فارسی

JBL

Everest 100

هدفون بیسیم توگوشی (In-ear)



تهیه شده در بخش خدمات پس از فروش شرکت شاب

آدرس: تهران، چیدر، میدان ندا، پلاک ۵۸


تلفن: (۱۰ خط) ۲۲۶۸۶۸۱۸

www.shobtech.com
technical@shobtech.com




نکته مهم: امکان پاسخگویی به تماس تلفنی در این کالا وجود دارد ولی این کالا جهت استفاده به عنوان "هندزفری" مناسب نیست.


1) دید کلی - کلیدها و چراغها




دکمه چندکاره (MFB=Multi-Function Button)




قلبهای گوش ارگونومیک Freebit در سایزهای S, M, L




سرگوشیهای قارچی شکل در سایزهای S, M, L




۲) گیره کابل



۳) روشن کردن هدفون برای pair کردن




3a) روشن کردن بلوتوث برای pair کردن




وضعیت چراغ	عملکرد چراغ
وصل شده	آهسته
قطع شده	دوبار
شارژ کم باتری	آهسته


4) کنترل موزیک با دکمه چندکاره (MFB)




(۵) کنترل‌های بیشتر برای موزیک با دکمه چندکاره




(۶) کنترل تماس تلفنی با دکمه چندکاره



(۷) اتصال Multi-point



(۸) شارژ باتری



مشخصات هدفون JBL Everest 100 :

- Model: V100BT
- Driver size: 5.8mm
- Dynamic frequency response range:
10-22k Hz
- Driver sensitivity: 96dB / 1kHz, 1mW
- Maximum SPL: 103dB
- Microphone sensitivity: -42dBV/Pa
- Bluetooth® transmitted power: <4dBm
- Bluetooth® transmitted modulation:
GFSK $\pi/4$, DQPSK, 8-DPSK
- Bluetooth® spec: 4.1
- Bluetooth® profiles: A2DP V1.3, AVRCP
V1.5, HFP V1.6, HSP V1.2
- Battery type: Polymer Li-ion Battery
(3.7V, 60mAh x 2)
- Charging time: 2 hours
- Music play time: up to 8 hours
- Earbud dimension W x H x L (mm):
14.7 x 14.8 x 30.4
- Mic housing diemnsion W x H x L (mm):
9.1 x 7.2 x 42.3
- Weight (kg): 0.016